

## **OHM Cosmo / Lunar Vacuum Cleaner**

### **Important Safety Guidelines**

To ensure the longevity of the vacuum cleaner and your personal safety, please adhere to the following:

- **Read the instruction manual carefully before using the product.**
- **Usage Environment:** Use only in dry locations; do not use on wet surfaces or expose the vacuum cleaner to rain, snow, or moisture.
- **Prohibited Items:** Do not use the vacuum cleaner to pick up hard/sharp objects (for example glass, nails), liquids, matches, or hazardous materials like kerosene or soot.
- **Battery Care:**
  - Avoid charging or storing the vacuum cleaner in extreme temperatures. The recommended storage range is **18°C to 28°C**.
  - If stored for a long time, the battery must be recharged and used at least **every three months**.
- **Physical Safety:** Keep hair, loose clothing, and body parts away from moving parts and openings. Do not point the telescopic tube or accessories at eyes or ears.

### **Maintenance & Cleaning**

Regular maintenance prevents weak suction and extends the life of the motor.

#### **1. Dust Cup & Filters**

- **Emptying:** Use the **Dust Cup Slider** to empty the cup regularly. Empty it immediately if the "Dust Cup full" indicator appears.
- **Cleaning:** Periodically clean the filters, please refer to the instruction manual for directions. If you wash the roller or cyclone filter, allow them to **dry in natural light for 24 hours** before re-installing.

#### **2. Floor Brush & Obstructions**

- **Blockages:** If the "Floor brush blocked" indicator lights up, remove the roller and clear any trapped debris or foreign matter from the floor brush.
- **Telescopic Rod:** Regularly check the rod for clogs if you notice weak suction.

### 3. General Care

- Only use accessories and replacement parts recommended by **OHM Group Limited** to maintain warranty coverage.
- Clean the **Rear Filter Component** as instructed in the manual.